

Instructions for Loading the High Cube - Drop Frame Trailers



For additional information or questions please contact
Dillon Transportation @ 800-262-8772.

Truckload Weight Total is 40,000 lbs. or Less...

- * Freight must be loaded on pallets.
- * Freight must be loaded with a fork lift / tow motor. (Pallet jacks will not work because of the step).
- * On the deck, (4) standard size pallets and/or 9,000 lbs can be loaded.
- * Load the rest of the trailer as normal, but do not load past the trailer tandems.

Truckload Weight Total is 41,000 lbs. up to 44,000 lbs....

- * Freight must be loaded on pallets.
- * Freight must be loaded with a fork lift / tow motor. (Pallet jacks will not work because of the step).
- * On the deck, (4) standard size pallets and/or 9,000 lbs. can be loaded.
- * Just below the deck, load (1) single pallet centered in the trailer.
- * Double back the remainder of the pallets.
- * Do not load past the trailer tandems.

If a customer only needs to load (2) skids on the deck, see below on how to secure the pallets...



- Prior to loading the trailer place straps approximately halfway up the deck toward the nose of the trailer in order to insure the pallets can not slide forward.
- Load 2 pallets, side by side, on the remaining portion of the deck, place additional straps to secure the 2 pallets.
- Once the pallets on the deck are secure you can load the rest of the trailer as normal.